

Sony Cameras

	Alpha 7	Alpha 7II	Alpha 7R	Alpha 7R II	Alpha 7S	Alpha 7S II	Alpha 100	Alpha 200	Alpha 230	Alpha 290	Alpha 300	Alpha 330	Alpha 350	Alpha 380	Alpha 390	Alpha 450	Alpha 500	Alpha 550	Alpha 560	Alpha 580	Alpha 700	Alpha 850	Alpha 900	Alpha 3000	Alpha 6000	Alpha 6300	Alpha SLT A33	Alpha SLT A55V	Alpha SLT A57	Alpha SLT A58	Alpha SLT A65	Alpha SLT A77	Alpha SLT A77 II	Alpha SLT A99	NEX-6	NEX-7	RX1	RX10	RX100 II	HX60V
--	---------	-----------	----------	-------------	----------	-------------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	-----------	------------	------------	------------	---------------	----------------	---------------	---------------	---------------	---------------	------------------	---------------	-------	-------	-----	------	----------	-------

Nissin Model	Alpha 7	Alpha 7II	Alpha 7R	Alpha 7R II	Alpha 7S	Alpha 7S II	Alpha 100	Alpha 200	Alpha 230	Alpha 290	Alpha 300	Alpha 330	Alpha 350	Alpha 380	Alpha 390	Alpha 450	Alpha 500	Alpha 550	Alpha 560	Alpha 580	Alpha 700	Alpha 850	Alpha 900	Alpha 3000	Alpha 6000	Alpha 6300	Alpha SLT A33	Alpha SLT A55V	Alpha SLT A57	Alpha SLT A58	Alpha SLT A65	Alpha SLT A77	Alpha SLT A77 II	Alpha SLT A99	NEX-6	NEX-7	RX1	RX10	RX100 II	HX60V				
Di700A	●	●	●	●	●	●	●	●	●	●	○	●	●	●	○	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Air 1 Commander	●	●	●	●	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
i40	●	●	●	●	●	●	●	●	●	●	○	●	●	●	○	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i60A	●	●	●	●	●	●	●	●	●	○	●	●	●	○	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

- Compatible Model
- Firmware update is required
- Firmware update is required + Use the Sony Shoe Adaptor (ADP-MAA)
- Use the Sony Shoe Adaptor (ADP-AMA)
- No information available. TBC

	Nissin Flashes		Sony Flashes					
	i40 Sony	Di622 II Sony	Di866 II Sony	HVL-F32M	HVL-F42AM	HVL-F43M	HVL-F58AM	HVL-F60M
Air R Sony	●	●	●	●	●	●	●	●

- Compatible Model
- Use the Sony Shoe Adaptor (ADP-MAA)
- GN Mode. 25-49
- GN Mode. 50-65

Olympus Micro Four Thirds / Four Thirds Cameras

	E-M1 (OMD)	E-M5 (OMD)	E-M5 Mark II (OMD)	E-M10 (OMD)	E-M10 Mark II (OMD)	E-P1	E-P2	E-P3	E-P5	PEN-F	E-PL1	E-PL2	E-PL3	E-PL5	E-PL6	E-PL7	E-PM1	E-PM2	E-30	E-410	E-500	E-520	E-620	
Nissin Model																								
i60A (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i40 (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Di466 (Four Thirds)	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Di700A (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Air 1 (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

Panasonic Micro Four Thirds Cameras

	Lumix GX1	Lumix GX7	Lumix GX7 MK2	Lumix GX8	Lumix GH-1	Lumix GH-2	Lumix GH-3	Lumix G-1	Lumix G-2	Lumix G-3	Lumix G-5	Lumix G-7	Lumix DMC-G6	Lumix LX100	Lumix G-10	Lumix GF-1	Lumix GF-2	Lumix DMC LX3	Lumix DMC LX5	Lumix DMC LX7	Lumix FZ-200		
Nissin Model																							
i60A (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
i40 (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Di466 (Four Thirds)	●	●	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Di700A (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Air 1 (Four Thirds)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●

- Compatible Model
- Hi-Speed sync not supported
- Camera may become unstable during EVF mode



Compatibility Chart

Last update: Jan 2017

Fujifilm Cameras																						
	X-T1 / X-T1 GS	X-T2	X-T10	X-Pro2	X-Pro1	X-E2S	X-E2	X-E1	X-M1	X-A2	X-A1	X-100T	X-100S	X-100	X-70	X-30	X-20	X-10	X-S1	HS50EXR	HS30EXR	HS20EXR
Nissin Model																						
i40 (Fujifilm)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i60A (Fujifilm)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
Di700A (Fujifilm)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
Air 1 (Fujifilm)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○

- Compatible Model
 - Fujifilm camera's firmware update is required. For more information, please visit the fujifilm official website.
- *Currently the Fujifilm system does not support High speed synchronize function.